

While listening to calls on your cell phone sent via The Fire Horn / Radio Bridge, there are options that allow you to stay in tune with what is going on right now while also hearing the beginning of a dispatch.







If you miss a call, you can replay it by dialing (270) 908-4254 and pressing 1.

Feedback is always appreciated.
Service and Support are available 24/7

(855) 347-3476

service@thefirehorn.com



- 1

While listening to your calls, you can choose to listen for over 40 seconds by pressing 1 at any time.
- 4

Calls can be rewinded to the start by pressing 4.
- 6

If you call back, or want to fast forward to the latest radio traffic, you can so this by pressing 6.
- 7

To rewind the call by 5 seconds, press 7.
- 9

To fast forward the call by 5 seconds, press 9.
- *

To respond to a call, simply press *. This will show you as en route to the last dispatched call, and allow you to listen for over the default 40 seconds.

If you hear a beep, that means your phone has gotten ahead of the radio bridge. At this point, you can either wait, or press 4 to hear the start of the call.